# CGO2+ camera update instruction (2.8.01)

1. Format a microSD card, copy the downloaded file 'cgo2gb_2.8.01_firmware.bin' in the root directory of the microSD card.

2. Insert the microSD card to CGO2+ gimbal.

Camera LED Status Indicator

3. Power on the gimbal (either connect it to TYPHOON or STEADY GRIP). The camera LED indicator blinks purple when CGO2+ camera is being updated. After updating, the camera LED indicator will be off.

4. Power off the gimbal and restart it. The gimbal will be ready to use when you see solid green LED.

Note: Do not power off the CGO2+ gimbal during the update.